



100mm pin use jig for setting up

All holes to be drilled and  
tapped M12

Same as Ackerman H16 and EC460

Make	Volvo
Model	S3